

## POP-UP UNIT TIGE DE BOUCHON MOBILE CONJUNTO DE DESAGÜE AUTOMÁTICO

1 1/4" / 32 mm

1. Place plumber's putty under flange ①.
2. Thread pop-up assembly ② washer ③, and nut ④, to flange under sink. Tighten nut.
3. Insert lift rod ⑤ through faucet and attach to extension strap ⑥.
4. Insert pivot rod ⑦ into pop-up and secure with nut ⑧.
5. Attach pivot rod to extension strap with clip ⑨.
6. Check for leaks

1. Placer le mastic de plombier sous la flasque ①.
2. Monter le bouchon mobile ② la rondelle ③, et l'écrou ④, à la flasque en-dessous de l'évier. Serrer l'écrou.
3. Insérer la tige de levée ⑤ par le robinet et attacher l'armature de rallonge ⑥.
4. Insérer la tige de pivot ⑦ dans le bouchon mobile et fixer avec l'écrou ⑧.
5. Attacher la tige de pivot à l'armature de rallonge avec l'attache ⑨.
6. Vérifier l'absence de fuites.

1. Coloque masilla de plomero a debajo del collarín ①.
2. Coloque el conjunto de desagüe automático ②, la arandela ③ y la tuerca ④ en el tubo debajo del lavabo. Apriete la tuerca.
3. Inserte la varilla elevadora ⑤ a través del grifo y coloque la abrazadera de extensión ⑥.
4. Inserte la varilla pivote ⑦ dentro del conjunto de desagüe automático y asegúrela con la tuerca ⑧.
5. Sujete la varilla pivote a la abrazadera de extensión usando el sujetador ⑨.
6. Revise si hay fugas.

